

Outdoor 18pcs par light



USER MANUAL

Outdoor 18pcs par light



CAUTION

Unplug mains lead before opening the housing!

First thanks for your use our LED par light.

Everyone involved with the installation,operation and maintenance of this device has to
↑ be qualified

↑ follow the instructions in this manual and consider this manual to be part of the total
product

↑ keep this manual for the entire service life of the product

↑ pass this manual on to every further owner or user of the product

↑ include every supplementary update with the original manual

Before your initial start-up,please make sure that there is no damage caused during
shipment.

Should there be any,don't use the device and consult your supplier.

I.SAFETY INSTRUCTIONS



CAUTION: Be careful with your operations.With a dangerous voltage

you can suffer a dangerous electric shock when touching the wires!

This device has left our premises in absolutely perfect condition.In order to maintain this
condition and to ensure a safe operation,it is absolutely necessary to follow the safety or
problems.

10CH Mode :

NO.	display	function
CH1	Dimmer	R,G,B,W ,Y,P dimmer,linear,from dark to bright
CH2	Strobe	R,G,B,W,Y,P strobe ,from slow to fast
CH3	Function select	0--50:DMX ;51--100:jump;101--150:fade;151--200 :pulse;201--255:sound control
CH4	Function speed	Function speed from slow to fast
CH5	R dimmer	Red dimmer,linear,from dark to bright
CH6	G dimmer	Green dimmer,linear,from dark to bright
CH7	B dimmer	Blue dimmer,linear,from dark to bright
CH8	W dimmer	white dimmer,linear,from dark to bright
CH9	Y dimmer	Red dimmer,linear,from dark to bright
CH10	P dimmer	Green dimmer,linear,from dark to bright

6CH Mode :

NO.	display	function
CH5	Red dimmer	Red dimmer,linear,from dark to bright
CH6	Green dimmer	Green dimmer,linear,from dark to bright
CH7	Blue dimmer	Blue dimmer,linear,from dark to bright
CH8	White dimmer	white dimmer,linear,from dark to bright
CH6	Yellow dimmer	yellow dimmer,linear,from dark to bright
CH6	Purple dimmer	Purple dimmer,linear,from dark to bright



Important: Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems.

If the device has been exposed to drastic temperature fluctuation(e.g.after delivery),don't switch it on immediately.The arising condensation water might damage your device.Leave the device switched off until it has reached room temperature. It must be used in an area with good ventilation.

Do not shake the device.Avoid brute force when installing or operating.This device is allowed to be operated with an AC of 90-250V.It falls under protection-class I.The power plug must be only be plugged into a protection-class i outlet.The yellowish-green or green conductor must be earthed!

Check the device and the power cord from time to time.Make sure the power cord is not crimped or damaged by sharp edges.Never let the power cord come into contact with other cables!Always connect the device to the mains least.Always disconnect from the mains,when the device is not in use or before cleaning it.Never leave the device running unattended.

Operate the device only after having familiarized with its functions.Keep away children and amateurs from the device!do not permit operation by person not qualified for operating the device.Most damages are the result of unprofessional operation!

There are no serviceable parts inside the device.Maintenance and service operations can be only carried by a qualified person.Please consider that unauthorized modifications on the device are forbidden due to safety reasons!Please note that damages caused by manual modifications on the device or unauthorized operation by unqualified persons are not subject to warranty.

If this device will be operated in any away different to the one described in this manual,it

Technical

Voltage: AC100-240V 50/60Hz

Rated power: 180W

Lamp quality: 18x18W 6in1 high power led

Dimming: 0-100% linear dimming

Strobe: 1-25Hz electrical strobe with variable speed, pre-programmed random strobe and pulse effects

DMX Channels: 6CH/10ch

Control mode: DMX512, Automatic and Master/ Slave mode
LCD display: digital display

LED digital display window table:

No.	display	function
1	A001	10 channels mode, （001—512） B/C change value
2	D001	6 channels mode, （001—512） B/C change value
3	CC00	Color jump, （01—99） B/C change speed
4	EE00	Color fade , （01—99） B/C change speed
5	FF00	Color gradient , Color pulse （01—99） B/C change speed
6	BEBF	Color sound control change
7	R220	Red, （000—255） B/C change value
8	G220	Green, （000—255） B/C change value
9	B220	Blue, （000—255） B/C change value
10	W220	white, （000—255） B/C change value
11	Y220	Yellow, （000—255） B/C change value
12	P220	Purple, （000—255） B/C change value